



**CRANK PULLEY BOLTS
5322G**

1. This kit includes both 3/8-16" and 3/8"-24" mounting bolts and lock washers.
2. Chevrolet V8 262-400 and 396-454 used 3/8-16" and 3/8-24" threads in OE harmonic balancers to attach the crank pulley.
3. Check threads in harmonic balancer. Determine the correct thread size to use for installation of crank pulley. Separate coarse and fine thread bolts and use correct bolts for your application.
4. Install mounting bolts, lock washers, and crank pulley onto harmonic balancer. Tighten to the manufacturer's torque specification.

199R11546

Date: 4-9-18



**CRANK PULLEY BOLTS
5322G**

1. This kit includes both 3/8-16" and 3/8"-24" mounting bolts and lock washers.
2. Chevrolet V8 262-400 and 396-454 used 3/8-16" and 3/8-24" threads in OE harmonic balancers to attach the crank pulley.
3. Check threads in harmonic balancer. Determine the correct thread size to use for installation of crank pulley. Separate coarse and fine thread bolts and use correct bolts for your application.
4. Install mounting bolts, lock washers, and crank pulley onto harmonic balancer. Tighten to the manufacturer's torque specification.

199R11546

Date: 4-9-18



**CRANK PULLEY BOLTS
5322G**

1. This kit includes both 3/8-16" and 3/8"-24" mounting bolts and lock washers.
2. Chevrolet V8 262-400 and 396-454 used 3/8-16" and 3/8-24" threads in OE harmonic balancers to attach the crank pulley.
3. Check threads in harmonic balancer. Determine the correct thread size to use for installation of crank pulley. Separate coarse and fine thread bolts and use correct bolts for your application.
4. Install mounting bolts, lock washers, and crank pulley onto harmonic balancer. Tighten to the manufacturer's torque specification.

199R11546

Date: 4-9-18